

Pertamina Oil & LPG
Terminal Makassar

Terminal Safety Information Booklet



Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1



Marine Region VII Sulawesi
Oil & LPG Terminal Makassar
Marketing Directorate – PT. Pertamina (Persero)
Jl. Hatta No. 1, Ujung Tanah
Makassar, South Sulawesi – 90173
Telp. +62 411 3629101

PERTAMINA MARKETING OPERATION REGION VII SULAWESI – MARINE TERMINAL

TERMINAL INFORMATION ON FACILITY, SAFETY, SECURITY AND POLLUTION PREVENTION REGULATION

Copyright © Pertamina Marine Region VII Sulawesi

This publication is copyright and is the property of Pertamina Marine Region VII Sulawesi.

Infringement of copyright or other intellectual property rights can result in liability to pay monetary damages. It is also forbidden to copy or to deal commercially with infringing copies of this document.

This document is confidential to the Pertamina Marine Region VII Sulawesi and is provided to all recipients in circumstances of confidence.

In particular, no part of this document may be disclosed or provided to any person or organization without the authorization of Pertamina Marine Region VII Sulawesi. Furthermore, no reproduction of any part of this document in any form or by any means including, but not limited to, electronic, photocopying, recording or otherwise, may take place without the written consent of Pertamina Marine Region VII Sulawesi.

Unlawful disclosure of confidential information can result in liability to pay monetary damages for any losses resulted from that act.

REVISION	DESCRIPTION	APPROVAL	DATE
1	-	Aditya Setyawan Region Manager Marine VII	18 Sep 2017
		Salman Kadili Sr. Spv. Marine Operation	18 Sep 2017

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

TABLE OF CONTENTS

TABLE OF CONTENTS	2
PREFACE	5
SECTION I – TERMINAL INFORMATION	6
1.1 POSITION	6
1.2 BERTH DESCRIPTION	6
1.3 BERTH DATA.....	6
1.3.1 BERTH I.....	6
1.3.2 BERTH II.....	7
1.3.3 BERTH III.....	8
1.4 CONTROLLING UKC	8
1.5 SHIP TRANSIT THROUGH MAKASSAR STRAIT	8
1.5.1 POSITION AND FUNCTION	8
1.5.2 APPROACH AND ENTRY	8
1.5.3 WEATHER AND CLIMATE	9
1.5.4 PILOTAGE AND TUGS.....	9
1.6 MINIMUM MOORING REQUIREMENTS.....	9
1.6.1 SHIPS.....	9
1.6.2 BARGES.....	9
1.6.3 EXCEEDING MINIMUM MOORING.....	9
1.6.4 WINCHES AND LINE HANDLING	10
1.6.5 BERTH LAY-OUT	10
1.7 PILOTAGE	12
1.8 TUG REQUIREMENTS	12
1.9 BERTHING MANEUVERS	12
1.10 BERTH EVACUATION ROUTES.....	13
1.11 PRE-ARRIVAL INFORMATION.....	14
SECTION II – OPERATIONAL INFORMATION	15
2.1 WIND LIMITS	15
2.2 ELECTRICAL STORMS	15
2.3 PERSONAL PROTECTIVE EQUIPMENT (PPE).....	15
2.4 TERMINAL CONTACT INFORMATION.....	16

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

2.5	OFFICIAL LANGUAGE.....	16
2.6	COMMUNICATIONS	16
2.7	RESPONSIBILITY OF OWNER AND MASTER.....	17
2.8	VESSEL COMPLIANCE AND TERMINAL SAFETY INSPECTION.....	17
2.9	PRE-TRANSFER CONFERENCE	17
2.10	SHIP/SHORE SAFETY CHECK LIST	18
2.11	SAFETY LETTER TO MASTER	18
2.12	GANGWAYS AND LADDERS	18
2.13	TERMINAL SMOKING REGULATIONS	18
2.14	HEALTH AND ENVIROMENTAL HAZARDS ASSOCIATED WITH CARGO.....	19
2.15	CARGO TRANSFER	19
2.16	PERSON IN CHARGE (PIC)	19
2.17	REQUIREMENTS DURING TRANSFER.....	19
2.18	DANGEROUS CARGO SIGNAL.....	20
2.19	VESSEL-TO-SHORE VOLUME COMPARISONS	20
2.20	TANK CLEANING/TANK ENTRY	20
SECTION III – SAFETY AND SECURITY INFORMATION		21
3.1	EMERGENCY DEPARTURE.....	21
3.2	FIRE AND SAFETY	21
3.2.1	EMERGENCY EQUIPMENT	21
3.2.2	TERMINAL FIRE SYSTEM	21
3.2.3	FIRE AND SMOKING SAFETY NOTICES	21
3.3	EMERGENCY STOP	22
3.4	TERMINAL SECURITY	22
3.5	VESSEL/FACILITY SECURITY INTERFACE	22
3.6	TAKING PHOTOGRAPHS	23
3.7	WEAHER FORECASTS	23
3.8	ELECTRICAL EQUIPMENT	23
3.9	SHORE LEAVE	23
SECTION IV – ENVIRONMENTAL INFORMATION		24
4.1	PRODUCT CONTAINMENT	24
4.1.1	BERTH.....	24
4.1.2	VESSEL	24
4.2	POLLUTION RESPONSE	24

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

4.2.1 POLLUTION REPORTING PROCEDURES.....	24
4.2.2 ACTION TAKEN IN THE EVENT OF OIL SPILL	25
4.3 GARBAGE RECEPTION	25
SECTION V – MISCELLANEOUS INFORMATION AND REQUIREMENTS	26
5.1 DRUGS, ALCOHOL, AND FIREARMS POLICY	26
5.3 LOADING PROVISIONS AND STORES	26
5.4 OTHER CRAFT ALONGSIDE	27
5.5 BUNKERING/FUELING	27
5.6 FRESH WATER	27

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

PREFACE

This booklet is addressed to the Masters, owners, operators, and agent of vessels that call at the Pertamina Oil & LPG Terminal Makassar. This booklet contains information that is applicable to the Pertamina Oil & LPG Terminal Makassar and is not represented as complete in every aspect of safe and pollution-free cargo-transfer operations.

This information is not intended to relieve any vessel or Master of the responsibility to safely berth, moor, and sail the vessel and to use whatever assistance over and above these requirements he/she feels are necessary. This information does, however, represent the minimum requirements for the terminal. Berth personnel will have authority in seeing that these requirements are met.

The Master or person in charge of any vessel, while at the terminal, shall have adequate knowledge of these rules and regulation and ensure that his crew members are fully informed of these requirement. Vessels that do not comply with all the requirements may not be permitted to berth or may be asked by the terminal representative to immediately disconnect and leave the berth.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

SECTION I

TERMINAL INFORMATION

1.1 POSITION

Latitude : 05° 06' 44.33" South

Longitude : 119° 24' 37.54" East

Name : Pertamina Marketing Operation Region VII Oil & LPG Terminal Makassar

Operator : Pertamina Marine Region VII Makassar

Street Address : Jl. Hatta No. 1, Ujung Tanah

Town : Makassar

State : South Sulawesi

Zip : 90173

Phone : +62 411 3629101

1.2 BERTH DESCRIPTION

Pertamina Oil & LPG Terminal Makassar (Pertamina Makassar Terminal) is a private terminal owned by PT. Pertamina (Persero) – Marketing Operation Region VII and operated by Pertamina Marine Region VII Makassar. The Pertamina Makassar Terminal is a part of Makassar Port, has three berths which are capable of loading, unloading, and bunkering ships or barges. The berths are pile-supported concrete cap jetties situated along the Makassar Strait. Each of the berths is fully operational 24 hours a week.

1.3 BERTH DATA

1.3.1 BERTH I

Type	: Jetty (Dolphin) – Sea Water
Depth alongside berth	: 9 meters
Safe Draft	: 8 meters
Height of Jetty (mean sea level)	: About 2.5 meters
Max. Displacement of ship	: Max. 23.500 tons
Max. DWT of ship	: Max. 19.000 tons
Max. LOA	: Max. 169 meters
Min. Parallel Body Length	: Min. 49 meters
Geographic Position	: 05°06'44.33"S / 119°24'37.54"E
Night Navigation Restriction	: 24 Hours Operation

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

Under normal condition it is capable of handling the following product(s) :

No	Product	Hose/Arm	Disch. Rate (kL per Hour)	Max. Pressure (kg/cm ²)
1	PREMIUM	1 x 8"	500	6
2	KEROSENE	1 x 8"	500	6
3	SOLAR (HSD)	1 x 8"	500	6
4	AVTUR (JET A-1)	1 x 8"	400	6
5	PERTAMAX	1 x 6"	500	6
6	MFO	1 x 6"	500	6
7	FAME	1 x 8"	500	6
8	LPG (PRESSURIZED)	1 x 6" for liquid 1 x 4" for vapour	180	9

1.3.2 BERTH II

Type	: Jetty (Dolphin) – Sea Water
Depth alongside berth	: 8 meters
Safe Draft	: 7 meters
Height of Jetty (mean sea level)	: About 2.5 meters
Max. Displacement of ship	: Max. 8.100 tons
Max. DWT of ship	: Max. 6.500 tons
Max. LOA	: Max. 100 meters
Min. Parallel Body Length	: 36 meters
Geographic Position	: 05°06'43.44"S / 119°24'42.97"E
Night Navigation Restriction	: 24 Hours Operation

Under normal condition it is capable of handling the following product(s) :

No	Product	Hose/Arm	Load/Disch. Rate (kL per Hour)	Max. Pressure (kg/cm ²)
1	PREMIUM	1 x 6"	250 / 500	6
2	KEROSENE	1 x 6"	300 / 500	6
3	SOLAR (HSD)	1 x 6"	250 / 500	6
4	AVTUR (JET A-1)	1 x 6"	- / 400	6
5	PERTAMAX	1 x 6"	- / 500	6
6	MFO	1 x 6"	200 / 400	6
7	FAME	1 x 6"	- / 100	6
8	LPG (PRESSURIZED)	1 x 6" for liquid 1 x 4" for vapour	- / 180	11

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

1.3.3 BERTH III

Type	: Jetty – Sea Water
Depth alongside berth	: 10 meters
Safe Draft	: 9 meters
Height of Jetty (mean sea level)	: About 3 meters
Max. Displacement of ship	: Max. 1.500 tons
Max. DWT of ship	: Max. 1.000 tons
Max. LOA	: Max. 55 meters
Min. Parallel Body Length	: N/A
Geographic Position	: 05°06'47.93"S / 119°24'34.93"E
Night Navigation Restriction	: 24 Hours Operation

Under normal condition it is capable of handling the following product(s) :

No	Product	Hose/Arm	Load. Rate (kL per Hour)	Max. Pressure (kg/cm ²)
1	SOLAR (HSD)	1 x 3"	50	3
2	MFO	1 x 3"	30	3

1.4 CONTROLLING UKC

As of the date of this revision, the following maximum UKC apply to Pertamina Makassar Terminal. Every vessel calling to Pertamina Makassar Terminal shall maintain her controlling UKC not to exceed:

- Approaching the berth : 1.5 meters
- While alongside : 1 meters

These controlling UKC requirement are guidelines only. Variances may be considered on an individual basis.

1.5 SHIP TRANSIT THROUGH MAKASSAR STRAIT

1.5.1 POSITION AND FUNCTION

Makassar (05°08'00"S / 119°24'00"E), is a central commercial port of Eastern Indonesia, and is situated on the South edge of Makassar Strait, on the mainland coast of Southern Sulawesi. It has a major oil terminal with advanced cargo & container handling facilities and one of the largest passenger ship terminal in Sulawesi. Makassar port also plays a vital role in export/import trading of various commodities.

1.5.2 APPROACH AND ENTRY

The entrance channel of Makassar is 25 miles long and 150 meters wide with a min. depth of 10 meters and max. depth of 16 meters. The ocean basin is consist of sand/clay.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

1.5.3 WEATHER AND CLIMATE

Tidal

Top High	: 2.40 m LWS
Average High	: 1.55 m LWS
High High Water Spring	: 1.80 m LWS
Mean Sea Level	: 0.90 m LWS
Low Low Water Spring	: 0.00 m LWS
Chart Datum	: 0.00 m LWS

Wind

Max. Speed : 2 – 25 knots

Temperature

Average : 24° - 31° C

1.5.4 PILOTAGE AND TUGS

Pilotage is compulsory for vessels more than 500 GT in gross volume and is operated by PT. Pelabuhan Indonesia (Pelindo) IV Makassar. Harbour pilot for Makassar are embarked in the vicinity of Tallo River (Port hand) or in the ship anchorage area. There are 4 (four) units of Tugboat available and are normally stationed near the Soekarno & Hatta Quay.

1.6 RECOMMENDED MINIMUM MOORING REQUIREMENTS

Minimum mooring requirements have to be met in order to comply with the terminal wind limits for safe mooring and transfer of cargo.

1.6.1 SHIPS

Ship's Size				Forward			After		
				Head Lines	Breast Lines	Spring Lines	Stern Lines	Breast Lines	Spring Lines
1.	10.000	-	20.000 DWT	3-4	2	2	3-4	2	2
2.	1.500	-	10.000 DWT	3	2	2	3	2	2

1.6.2 BARGES

- Barges with 80 m³ and greater capacity shall deploy a minimum of 8 (eight) mooring lines.
- Barges with less than 80 m³ capacity shall deploy a minimum of 6 (six) mooring lines.

1.6.3 EXCEEDING MINIMUM MOORING

Additional lines may be used at the discretion of the vessel Master or may be required depending on unfavorable weather conditions.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

1.6.4 WINCHES AND LINE HANDLING

Terminal personnel will handle shore side mooring operations, while terminal mooring gangs will assist the pulling of the hawser manually.

1.6.5 BERTH LAY-OUT

The below berth layout diagram is for Master's reference of best mooring practice.




Figure 1 – Layout of Jetty I

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1




Figure 2 – Layout of Jetty II




Figure 3 – Layout of Jetty III

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

1.7 PILOTAGE

Pilotage is compulsory. Vessel calling at Makassar Port has to confirm their arrival time to Marine Operation Station at least 8 hours before arrival and 4 hours before departure. Vessel shall report to Makassar Marine Operation Station on VHF Ch 09.

If the Pilot is on board or on the way to the vessel, please switch to VHF Ch 12 for reports regarding pilotage activities with Makassar Coast Radio Station.

1.8 TUG REQUIREMENTS

Below table towage guidelines are intended to assist the terminal user to determine the number of tugs required for a vessel's movement within the port waters of Makassar.

No	Ship's LOA (m)	Number of Tugs	Min. Total Power (HP)
1	70 - 150	1	2.000
2	150 - 250	2	6.000

The number of tugs required is determined, among other factors, by the size and ship handling characteristics of the vessel, the peculiarities of berth and its approaches, and the prevailing conditions e.g. tidal streams, weather. The pilot upon boarding may thus, in consultation with the master, cancel or order additional tugs if required.

1.9 BERTHING MANEUVERS

Vessels need to approach the dock at an approximate angle of 5 degrees or less. Velocity cannot exceed 0.3 kts. Especially for berth no 1 the ship's speed when making contact to the berth should not exceed 0.19 kts.

All vessels calling on, attending to or are under contract providing support to or at any Pertamina Oil & LPG Terminal Makassar will ensure that "Hand Steering" is used when approaching the terminal or facility for berthing. The use of "auto" pilot is prohibited unless permission is given by the terminal. Nothing in this requirement shall prevent the Master from taking such action deemed necessary and prudent, in the ordinary practice of good seamanship, for the safety of the vessel or crew.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

1.10 BERTH EVACUATION ROUTES

Follow the evacuation route marked with **blue arrows** to the nearest assembly point in case of emergency. More details are described within below picture :




Figure 4 – Evacuation Route

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

1.11 PRE-ARRIVAL INFORMATION

Following pre-arrival information need to be be communicated to Terminal :

1. ETA on daily basis, 72 hrs, 48hrs, 24 hrs,and 6hrs before arrival
2. Validity and copy of Pertamina Safety Approval (PSA)
3. Quantity of cargo (if applicable)
4. Ship's security level
5. IMO crew list.
6. Other important information for terminal.

The required information shall be sent to the following :

1. Pertamina Makassar Marine Operation email address :
ops.marine.mks@pertamina.com; Telp +62 411 362 9101; Mobile +62 4609016.
2. PIC Pertamina Ship Agency : wildanum.mukholladun@pertamina.com

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

SECTION II

OPERATIONAL INFORMATION

2.1 WIND LIMITS

Berthing and unberthing maneuvers should normally not be conducted in winds in excess of 20 knots. Once berthed, if storm winds in excess of 25 knots are forecasted, the berths should be vacated and Master shall make arrangements for departure in advance of storm arrival to permit safe movement. In any event, all maneuvers shall be based on mutual agreement of the Master and Harbour Pilot, subject to assessment of the effect of current and weather on the ability to conduct safe ship handling.

The Pertamina Makassar Terminal's maximum safe-operation wind limit is 25 knots. Wind limit will be expressed as a sustained wind blowing for an average of 30 seconds or longer. When the wind limit is reached, cargo transfer shall stop, and all transfer equipment shall be drained and disconnected, if safe to do so. After evaluation of weather forecast, consideration should also be given on deploying additional mooring lines or arranging for a standby tug.

2.2 ELECTRICAL STORMS

When an electrical storm is in the vicinity, all cargo discharge or loading operations will cease. All compartment hatches and loading headers will be closed. The vessel and terminal will remain in this inactive state until the electrical storm has moved out of the area.

2.3 PERSONAL PROTECTIVE EQUIPMENT (PPE)

Contractors are required to follow the Pertamina Marine Region VII Makassar policy while on the berth. While onboard their vessel, the crew are allowed to follow their own company policies. The Pertamina Marine Region VII policy requires the following:

- Hard Hat (safety helmet)
- Safety Shoes
- Coverall

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

2.4 TERMINAL CONTACT INFORMATION

For mailing or contact information, please refer to the following:

- **Marine Region VII Makassar**
Marketing Directorate – PT. Pertamina (Persero)
Hatta Street No. 01
Ujung Tanah, Wajo, Makassar City
Phone. +62 411 362 9101

- Marine Operation : Email. ops.marine.mks@pertamina.com
Phone. +62 411 362 9101
Radio VHF Channel 09
- Berth Schedule : Email. ops.marine.mks@pertamina.com
Phone. +62 411 362 9101
Radio VHF Channel 09
- Port Facility Security Officer : +62 411 871 181
- Puskodal MOR VII : +62 411 871 181 / 7011
- HSSE Region VII : +62 411 871 181 / 7401
- S&D Region VII : +62 411 871 181 / 7501
- Domestic Gas Region VII : +62 411 871 181 / 7191
- Medical Office Region VII : +62 411 871 181
- Makassar Firefighter Office : +62 411 878 797
- Port Area Firefighter : +62 411 316 549

Or you can go to the nearest Security Post to have access for internal telephone call.

All correspondence regarding the management and operations of the Pertamina Oil & LPG Terminal Makassar should be directed to the Terminal Supervisor.

2.5 OFFICIAL LANGUAGE

The official language of the terminal is English for foreign ships and Bahasa Indonesia for Indonesian Flag ships. All vessels must have personnel on duty at all times who can communicate in and understand either English or Bahasa Indonesia with the Terminal personnel.

2.6 COMMUNICATIONS

During the pre-transfer conference, a handheld UHF terminal radio set to Chanel 9 will be issued to PIC of ship/barge. Terminal operations personnel will have similar radios monitoring the same shanel. The following will be required of the vessel :

- The radio will kept on at all times and in the possession of a person who understand and speaks either English or Bahasa Indonesia.
- If radio fails, the secondary means of communication shall be agreed before cargo operation start (i.e telephone; other VHF Channels or sound signals).
- During the transfer operation, the vessel must have its main Radio/GPS turned off.

Radio checks must be conducted every hour to ensure communication are working.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

2.7 RESPONSIBILITY OF OWNER AND MASTER

The owner and/or the operator of vessel, as well as the Master of each vessel using the terminal facilities, is responsible for condition of that vessel, and the Master shall be responsible for the safe and business-like conduct of personnel and operations onboard the vessel while alongside our terminal

The terminal takes no responsibility for condition of any vessel alongside the terminal, nor does the terminal take any responsibility for the safe conduct of operations onboard the vessel, at a minimum, all procedures used by the vessel must conform to the latest editions of the *international Safety Guide of Oil Tankers and Terminals (ISGOTT)* and *Mooring Equipment Guidelines (MEG)* as well as all applicable international, national and regional regulations.

2.8 VESSEL COMPLIANCE AND TERMINAL SAFETY INSPECTION

All ships and barges loading or unloading at the Pertamina Oil & LPG Terminal Makassar must comply with all state, and local laws, as well as Pertamina regulations and policies.

If the vessel is boarded by Pertamina Marine Terminal Safety Inspector and does not pass inspection, has no valid PSA certificate, or is found to be unfit to transfer product, the vessel may be asked to leave the berth. This also applies to all other government agency reserves the right to cease operations and ask the vessel to leave the berth if any safety or compliance issues are noted.

2.9 PRE-TRANSFER CONFERENCE

Before the transfer of any cargo, a conference will be conducted between the vessel PIC and the terminal PIC. The purpose of the conference is to ensure that the vessel and the terminal are fully informed and advised of the entire transfer plan and that all security and safety requirements are in place.

During the conference, the following will be discussed:

- Product and amounts to be transferred.
- Cargo load/discharge plan.
- Rates and pressure requirements.
- Any usual safety or security requirements.
- Communications system for transfer operations and signal for emergency stop.
- Quality of Inert Gas System if available.
- Venting method.
- Whether or not the cargo include toxic component for example H₂S, benzene, lead additives or mercaptans.
- Cargo characteristic.
- Restrictions for transfer operations both shore and ship.
- Ballast/deballasting.
- Applicable security measure for current Security Level.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

2.10 SHIP/SHORE SAFETY CHECK LIST

A ship/shore safety check list must also be completed to meet the requirements of ISGOTT. This is to be completed in conjunction with a ship's officer by the Pertamina Marine Inspector.

2.11 SAFETY LETTER TO MASTER

Dear Captain

Responsibility for the safe conduct of operations while your ship is at this terminal rests jointly with you, as Master of the ship, and with the responsible Terminal Representative, we wish, therefore, before operations start, to seek your full cooperation and understanding on safety requirements set out in the ship/shore Safety Check list, which are based on safe practices that are widely accepted by the oil and tanker industries.

We expect you, and all under your command, to adhere strictly to these requirements throughout your ship's stay alongside this terminal and we for our part, will ensure that our personnel do likewise, and co-operate fully with you in the mutual interest of safe and efficient operations.

Before the start of operations, and from time to time thereafter, for our mutual safety, a member of the terminal staff, where appropriate together with a Responsible Officer, will make a routine inspection of your ship to ensure that elements addressed within the scope of Ship/Shore Safety Check-List are being managed in an acceptable manner. Where corrective action is needed, we will not agree to operations commencing or, should they have been started, we will require them to be stopped.

Similarly, if you consider that safety is being endangered by any action on the part of our staff or by any equipment under our control, you should demand immediate cessation of operations.

There can be no compromise with safety

2.12 GANGWAYS AND LADDERS

Ships or Barges calling at Pertamina Oil & LPG Terminal Makassar shall liaise with Terminal personnel which gangway/ladder shall be used, depending on landing configuration. Gangways, if any, shall be properly rigged and landed safely onto the berth with handrails. The use of a safety net is mandatory except for the gangway which is fixed to the shore and provided with a permanent system of handrails made of structural members.

2.13 TERMINAL SMOKING REGULATIONS

Smoking is strictly prohibited within the terminal property.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

2.14 HEALTH AND ENVIRONMENTAL HAZARDS ASSOCIATED WITH CARGO

Vessel should have available on request and MSDS the cargoes being transferred. Information in any toxic substances in the cargo should be highlighted during the pre-transfer conference to enable the adoption of proper precautions, if needed, to minimize the impact on personnel.

2.15 CARGO TRANSFER

Cargo transfer operation shall comply with the ISGOTT recommendation at all times. Deviation from these requirements shall be discussed with and approved by terminal.

During the handling of volatile petroleum and the loading of non-volatile petroleum into tanks containing hydrocarbon vapour, and while ballasting after the discharge of volatile cargo, all cargo tank lids should be closed and secured. Closed oil cargo transfer is required throughout the operations.

Cargo tank lids or coamings should be clearly marked with the number and location (port, centre, or starboard) of the tank they serve.

Vessel shall refer to berth information on previous pages to see connection used, rate of loading and discharge working pressure for each grade. Before arriving at the Pertamina Oil & LPG Terminal Makassar, all equipment on vessel to be used for mooring, cargo handling, and fire protection should be inspected and confirmed safe for use.

It is the shipping company's responsibility to contact the terminal, either directly or through an agent, should the vessel be in non-compliance with any State, or local laws, rules or regulations, or with any part of this manual. The shipping company must ensure that any conflict is resolved before the vessel's arrival at the terminal.

2.16 PERSON IN CHARGE (PIC)

Both the terminal and the vessel must have a trained, qualified, and designated PIC on duty at all times.

Terminal requires at least one senior officer from each department to stay onboard throughout the operation.

2.17 REQUIREMENTS DURING TRANSFER

Pertamina Oil & LPG Terminal Makassar requires the following during the transfer:

- The vessel will have watchmen on the deck and in line of view of the transfer piping, hoses and manifold at all times.
- Moorings must be tended conscientiously and kept taut at all times.
- Gangway and nets must be attended regularly throughout the operations.
- If the vessel experiences excessive movement away from the berth or in either direction along the berth, all cargo transfer operations shall be stopped and manifold valves closed. Operations will not be resumed until the mooring situation has been corrected.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

- Transfer hoses or loading arms must be checked periodically for leaks, kinking, and proper positioning with the up and down movement of the vessel.
- The waters arounds the vessel will be checked periodically for any evidence of spilled product
- Cargo transfer (loading/discharging) shall be started with minimum rate or pressure possible. Ship and shore staff shall check their installation for leaks and other harmful conditions.
- Rate/pressure of cargo transfer shall be increased gradually until maximum.

2.18 DANGEROUS CARGO SIGNAL

The vessel shall display a red warning light by night and a red “B” flag by day to advise passing traffic that the vessel has dangerous cargo on board.

2.19 VESSEL-TO-SHORE VOLUME COMPARISONS

Vessels either loading or unloading will conduct periodic volume and flow rate comparisons with the terminal. Frequency and timing of these comparisons will be discussed and agreed upon during the pre-transfer conference. If there is a difference greater than 10%, the transfer will be stopped until the difference is reconciled.

2.20 TANK CLEANING/TANK ENTRY

Tank cleaning is not allowed at any time the vessel is alongside the Pertamina Oil & LPG Terminal Makassar. Any tank entry must be pre-approved by the terminal.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

SECTION III

SAFETY AND SECURITY INFORMATION

3.1 EMERGENCY DEPARTURE

During an emergency situation at the Pertamina Oil & LPG Terminal Makassar, a vessel may be required to leave the berth on short notice. Masters will ensure that the vessel is ready at all times to sail on short notice after cargo hoses are disconnected. Immobilization of vessel during berthing at the terminal is strictly prohibited.

3.2 FIRE AND SAFETY

3.2.1 EMERGENCY EQUIPMENT

Vessels must maintain all emergency equipment. The equipment must be inspected and maintained in a safe, ready-to-use condition at all times. All ship's crew must be trained in the use of this equipment.

The terminal is equipped with oil spill response equipment and team to deal with pollution.

3.2.2 TERMINAL FIRE SYSTEM

The fire and evacuation alarm signal in case of fire within area of terminal including tanker berths consist of a loud, prolonged siren 4 x 30 seconds. Firefighting at the Pertamina Oil & LPG Terminal Makassar is done by the Pertamina Makassar Fire Brigade.

There are fire extinguishers located at the berths. These include wheeled units as well as handled extinguishers.

There are fire water and foam hydrants along the jetty trestle.

3.2.3 FIRE AND SMOKING SAFETY NOTICES

Warning notices are to be posted on the vessel for the following :

- Visitor restrictions.
- Mobile phone and other electronic equipment must be switched off.
- No open lights, matches, or lighters.
- Smoking restriction and designated areas.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

3.3 EMERGENCY STOP

An emergency situation is considered to have arisen when any of the following occur:

- Oil is released on the deck of the vessel or the berth.
- Oil is released into the water.
- Failure of means of communications; primary and secondary.
- Fire occurs on the vessel, berth, or anywhere in the terminal.
- Any other major incident that seriously affects safety of the vessel or the terminal.

As soon as an emergency situation is declared over the radio or continuous prolonged whistle/ general alarm sound where each blast shall not be less than 60 second, the vessel shall immediately cease all transfer operations, secure the deck, and stand by to drain and disconnect all hoses. Resumption of the transfer will begin only with the agreement between vessel and terminal personnel.

3.4 TERMINAL SECURITY

Access to the Pertamina Oil & LPG Terminal Makassar is strictly limited to its personnel, vessel crews, pre-approved maintenance or store contractors, government agencies, ship's agent, and cargo inspectors. Any other visitors must be first approved by Security Section of Pertamina Oil & LPG Terminal Makassar. Listed below are the requirements for entrance to the Pertamina Makassar Terminal.

1. Contractor list and visitor list must be faxed to terminal 24 hrs before arrival of the vessel.
2. Contractor and visitor must have picture ID.
3. Visitors must be willing to submit to a search of their vehicles by security personnel before entry to the terminal areas.
4. All Pertamina Makassar Terminal rules and regulations concerning safety must be adhered to by personnel entering the jetty area.
5. Security procedures for the terminal on various Security Levels are stated in the Pertamina Makassar Terminal Security Plan. If the Security Level is raised from 1 to higher level, the Pertamina Oil & LPG Terminal Makassar Facility Security Officer will notify all customers doing business at the terminal of the increased level and any additional security procedures. The current Security Level is displayed near the security post in every jetty.

Unless specifically informed by PFSO, terminal is operating at security level 1.

3.5 VESSEL/FACILITY SECURITY INTERFACE

After the arrival and berthing of the vessel, required security procedures will be discussed before any other action is taken. The discussion will include the current Security Level Declaration of Security, and any other security measures deemed necessary by the vessel or terminal.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

3.6 TAKING PHOTOGRAPHS

Permission to take photographs is given by the Pertamina Oil & LPG Terminal Makassar - HSSE Department and will only be approved under special circumstances.

3.7 WEAHER FORECASTS

Vessels should maintain a weather watch and monitor forecasts. Any weather alerts received by the terminal will be passed on to the vessel.

3.8 ELECTRICAL EQUIPMENT

Any electrical equipment powered by generators, fixed power souces, or batteries that are not classified as intrinsically safe are not allowed to be used while at the Pertamina Oil & LPG Terminal Makassar. This includes radios, pagers, cell phones, portable lighting, or any other equipment that is electrical but not approved for used in hazardous areas.

3.9 SHORE LEAVE

Shore leave is permitted at Pertamina Oil & LPG Terminal Makassar with following restriction.

- Walking or passing through the tank area is prohibited. Terminal provides walkway along the shore for crews who leave from jetty to front gate.
- Shore leave crew shall at least wear long sleeve shirt, safety helmet and safety shoes.
- Obey all safety rules and signs within terminal areas.
- Do not smoke within terminal areas and offices.
- Do not touch the terminal operational equipment.
- Switch off hand phone and other electronic devices.
- Report all incidents to the nearest terminal office or staff.
- No photograph.
- No firearns, cold steels, matches, lighters, and other destructive weapon \.
- Do not incite fighting and no horseplay.
- No drugs, narcotics, alcohol and other intoxicated substances.
- In case of emergency, please muster to nearest the Assembly Point.
- Emergency Signal within the terminal is prolonged siren frequency 4x30 seconds.

Vessel shall maintain at all times sufficient crew not less that 50% of ship's complement onboard to deal with emergency.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

SECTION IV

ENVIRONMENTAL INFORMATION

4.1 PRODUCT CONTAINMENT

4.1.1 BERTH

The Pertamina Oil & LPG Terminal Makassar has a cement containment area encompassing the manifold platform and containment trays at the receipt headers.

4.1.2 VESSEL

Vessels must plug all scuppers and drains before transfer to prevent any drippings or spills from draining to the river. Vessel must have sufficient means of draining, pumping, or cleaning up any oil on the deck.

4.2 POLLUTION RESPONSE

In accordance with federal and state-mandated oil spill response measures, the terminal is equipped with containment boom and other spill response equipment, which can be readily deployed in the case of an oil spill. Response vessels, as required, will be provided by Pertamina Marine Operation Makassar - Oil Spill Response Team.

Any vessel moored at the Pertamina Oil & LPG Terminal Makassar is required to have and maintain all pollution control equipment for use in case of an oil spill.

4.2.1 POLLUTION REPORTING PROCEDURES

In the event of any oil spill into the water, vessel shall inform Pertamina Marine Operation Makassar without delays. If a spill is from the vessel, terminal personnel will assist with notifications and response.

Important : in the event of an incident—spills to deck or water, groundings, collisions, allusions, fires, explosions, loss of propulsion or steering, fatalities or serious injuries (emergency evacuations from the vessel or man overboard), or any incident that results (or may result) in media coverage—immediately call the Terminal Supervisor

Upon calling this number, you will be asked some basic question about the vessel and nature of the incident. You will be required to provide a contact name and number for further details. A written summary of the incident and a summary of the investigation report, including corrective action(s) planned, shall be submitted within 30 days of the event directly to Pertamina Marine Operation Makassar.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

4.2.2 ACTION TAKEN IN THE EVENT OF OIL SPILL

- The following actions will be taken in the event of a spill.
- Shut down all transfer operations.
- Notify terminal/vessel/agent personnel immediately.
- Start management, response, and agency notification.
- Initiate a site safety plan.
- Start documentation of actions taken.
- Obtain Pertamina Oil & LPG Terminal Makassar approval before restaring the transfer.

4.3 GARBAGE RECEPTION

There are no Garbage reception facilities within Pertamina Oil & LPG Terminal Makassar.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

SECTION V

MISCELLANEOUS INFORMATION AND REQUIREMENTS

5.1 DRUGS, ALCOHOL, AND FIREARMS POLICY

No alcohol or illegal drugs are allowed to enter the terminal. Crew members under the influence of drugs or alcohol will be detained at the security office and have their company notified. Reasonable cause for detaining crew members is their speech, manner, behavior, and/or general appearance that may indicate that an individual is under the influence of drugs or alcohol. If a crew member is detained for any of cause above, the shipping company must have the person tested for drugs and alcohol, before granted entry to the terminal.

Firearms of any kind are not allowed in terminal's property, except for those carried by authorized law enforcement officers.

Every vessel alongside the Pertamina Oil & LPG Terminal Makassar must have an alcohol and drugs policy that meets or exceeds the standard as described in "The Oil Companies International Marine Forum Guidelines for the Control of Drugs and Alcohol on board Vessels".

5.2 REPAIR WORK PERMISSION

Repairs that involve **hot work** are not allowed at any time the vessel is alongside the Pertamina Oil & LPG Terminal Makassar. Any repairs or maintenance not requiring hot work must be pre-approved by the terminal. A list of any additional personnel and parts required to complete the repairs must be supplied to the terminal before arrival.

5.3 LOADING PROVISIONS AND STORES

Loading of provisions and stores is allowed at the Terminal with operational and security restrictions.

Operational: Contractor vehicles are not allowed on the berth. If shore side delivery is being made, provisions and stores must be hand-trucked down the berth to the vessel. With prior permission from the terminal, stores may also be delivered via launch.

Security: A list of personnel delivering the provisions must be supplied to the terminal before their arrival. Before they enter the berth area, they must show photo ID. If MARSEC levels rise, other restrictions may be applied. Contact the terminal if you have questions.

Pertamina – Marine Region VII Sulawesi			
Oil & LPG Terminal Makassar	Marine Terminal Information Booklet	Issued	18 th September 2017
		Revised	1

5.4 OTHER CRAFT ALONGSIDE

No craft is authorized to come alongside or remain alongside a vessel while handling hazardous cargo without permission from the terminal. The operator of the craft must be fully aware of all safety rules and regulation applying to the vessel/terminal and must comply.

5.5 BUNKERING/FUELING

Jetty I, Jetty II, and Jetty III are equipped with bunkering facilities (MFO & HSD). Please contact Pertamina Marine Operation Makassar or your agent for bunkering.

5.6 FRESH WATER

Fresh water supply is available from the Jetty. Please contact Pertamina Marine Operation Makassar or your agent in advance to request fresh water supply.